TROLLEY # 2024 (Bruce the Goose) 35 PAX (Max 32)

Keys: Located inside trolley on the floor next to the door, EXTRA SET UNDER GUIDE SEAT

Getting it started: check fluid levels, tires and lug nuts, turn key to on wait for engine to cycle then start

Gears: Lever on steering column

Brakes: Please downshift when possible, and not ride the brakes, when descending hills. "**M" IS ONLY USED WHEN DOWNSHIFTING FROM THE SHIFT LEVER**

Microphone: Wireless Headset that can be used for driver or guide. Charge headset when not in use, ie. when travelling to and from cruise terminal. Extra headset (not wireless) in Aquila bag under guide seat. That one plugs into transmitter.

Speakers: Small mic at console works well if guide is in a seated position

AC: none

Door: Switch outside under passenger side headlight to close/open the door, also above the door there is a switch. Electric switch on panel at driver's window.

Windows: slide and lock

Vents:

Fire Extinguisher: Located inside compartment under guide Seat

First Aid Kit: Located inside compartment under guide Seat

Fueling Up: Fuel up **PREMIUM GAS (NOT DIESEL and Not Regular)** on Driver side at rear tires.

Other: emergency exits on side and at rear windows

Other: **Triangles located under Guide seat**

Other:

At the end of the day: Sweep, and empty all garbage from unit, secure all windows to locked position

History of Major Work Done:

TROLLEY # 2018 (Lucy the Lobster) 35 PAX (max 32)

Keys: Under fire extinguisher on floor at right of door

Getting it started: check fluid levels

Gears: lever on steering column

Brakes: Please downshift when possible, and not ride the brakes when descending hills. **Tow Haul Mode locks transmission in low for descending hills.**

Microphone: Wireless Headset that can be used for driver or guide. Charge headset when not in use, ie. when travelling to and from cruise terminal. Extra headset (not wireless) in Aquila bag under guide seat. That one plugs into transmitter.

Speakers:

AC: none

Door: Electric switch on panel to left of driver's seat, reach in driver window to open and close

Windows: Slide openings on bottom, keep locked and closed at end of shift. **Never lock Driver Window**

Vents:

Fire Extinguisher: located to right of door

First Aid Kit: on wall to right of door, **Triangles** Located under Guide seat

Fueling Up: Fuel up **PREMIUM GAS (NOT DIESEL and Not Regular)** on Driver side at rear tires.

Other:

Other: Low Beam Headlights are on when lever is at the downmost position

Other: Driver side mirror creates severe blind spot, particularly for exiting Fort Howe hill

At the end of the day: Sweep, and empty all garbage from the unit. Leave all windows except driver in locked position

History of Major Work Done:

TROLLEY # 11 (Justin Beaver) 41 PAX (max 36-38)

Keys: Stored on top of the First Aid Kit above the door.

Getting it started: Lift back engine cover **(HEAVY)** and turn master switch to on position. Turn off at the end of the day.

Gears: Shift lever on dash

Brakes: **Please downshift when possible, and not ride the brakes when descending hills.**

Microphone: If it doesn't work, try flipping "dimmer light switch" near the floor. Driver-guide microphone located in overhead compartment in a box

Speakers: The volume for the microphone is inside the storage compartment.

AC: none

Door: Air operated, Release valve above the door

Windows: When rolling up summer windows, roll them towards the inside of the vehicle so that rain doesn't get inside the plastic. Secure all windows at completion of shift.

Vents:

Fire Extinguisher: located on left hand side of driver's seat.

First Aid Kit: Above the door, **Triangles** behind Driver

Fueling Up: Fuel up on passenger side

Other: Fuel gauge does not work reliably. **TROLLEY 11 MUST BE FILLED UP EVERY DAY IT'S DRIVEN.**

Other: Often have to turn off signal indicator manually after a turn.

Other: End of day idle for at least 5 mins prior to shut down. Sweep, empty garbage, close all windows.

History of Major Work Done: Cross members, new floor, and new interiors done in 2016. Cross members in 2013 by Maxxim

TROLLEY # 12 (Maple the Moose) 41 PAX (max 36-38)

Keys: Stored on top of the First Aid Kit above the door

Getting it started: Lift back engine cover and turn power switch to on position. Turn off at the end of the day.

Gears:

Brakes: **Please downshift when possible, and not ride the brakes when descending hills**

Microphone: If it doesn't work, try flipping "dimmer light switch" near the floor. At days end, dial on radio does not need to be turned off. If volume is affected, dial needs to be adjusted. Radio volume is ok to be adjusted. Leave on 87.5.

Speakers:

AC: none

Door: air operated

Windows: When rolling up summer windows, roll them towards the inside of the vehicle so that rain doesn't get inside the plastic. Use straps and snaps to secure.

Vents:

Fire Extinguisher:

First Aid Kit: Above the door

Fueling Up: Fuel up on passenger side. Don't fill the neck, as you will smell fumes inside the trolley. When it clicks, stop fueling.

Other: **Holds 38 PAX**

At the end of the day: After parking in the yard, let it run for 5 minutes before shutting off. Sweep out and turn off door air

History of Major Work Done: Major interior renovation and cross members 2016 Jeff Lynch, cross members in 2013 by Maxxim, transmission by Jensen's in 2012

BOSTON 313 (Neil the Seal) 35 PAX (Max 32)

Keys: Inside the cupboard above the door (the smaller one on the left)

Getting it started: Turn Master Switch on outside to the left of the door. Inside panel upper left corner. turn key part way, WAIT for "Wait to Start" light to turn off, then finish turning over engine.

Gears: Push buttons on dash. Don`t forget to push N when stopped and parked

Brakes: Pull yellow emergency brake when parked. **Please downshift when possible, and not ride the brakes when descending hills**

Microphone: Hand Held for guide, volume control on box

Speakers: Stereo must be turned on for microphone to work

AC: None

Door: Air Operated Valve for the door operation by driver's window. **Air Release valve located above the door is to be engaged while driving, and released at end of shift. When crossing train tracks, close the door when you actually go over tracks, so the door doesn't drag**.

Windows: lift upward and secure with wooden hand to secure. Please close completely at end of shift

Fire Extinguisher: By the driver **First Aid Kit**: Above the driver seat, **Triangles** under guide seat

Fueling Up: Fuel up on driver`s side. **Diesel fuel every 2nd Trip as gauge is not dependable**

Other: There is a control on the floor to start/stop a CD. **Front bumper will drag on pavement. Come out of the pier on an angle and slowly.**

Wipers: There are 2 knobs on the dash. 1 for the left and center wipers, and 1 for the right wiper.

Driver seat is air ride. The switch on the left brings it forward and back. Switch on the right moves it up and down.

At the end of the day: After parking in the yard, let it run for 5 minutes before shutting off. **Turn off Kill switch (switch DOWN) at the end of the day. Switch located outside trolley inside the panel left of door.**

History of Major Work Done: New batteries in 2016,

Trolley 2005 (Willow the Whale) 38 PAX (max 32)

Keys: Above the door in emergency cubby on red Air Release handle

Getting it started: turn on master power switch located on the front left hand side of the dash. Turn key to on position and engage starter when the wait to start light on dash goes out.

Gears: Push button control on dash at the left- mode selection will hold transmission in any gear selected

Brakes: **Please downshift when possible, and not ride the brakes when descending hills**

Microphone / Speakers: Hand held mic and controls located to right of the dash

AC: None

Door: Last switch on the left in toward the rear in the cluster of electric switches (electric over air control)

Windows: Most will open part way from the bottom, use wooden hands to secure

Fire Extinguisher: Located to the left of driver's seat on wall

First Aid Kit: Front left of driver's seat near fire extinguisher, **Triangles** behind Drivers seat

Fueling Up: Locked door on driver's side - key is on key ring

Other:

Wipers: Dials located in driver's compartment area on left

Driver seat: Adjustable air ride

At the end of the day: First, let it idle 3 to 5 minutes, sweep out debris, empty garbage, then turn off engine .

Then turn off master power switch, take air off door with Air Release handle in emergency compartment.

History of Major Work Done: